

MAKE: TOYOTA

TYPE: LandCruiser 55 Series

MODEL: FJ55

YEAR: 1970 – 1980

DETAIL: Station Wagon



TOY-51

FRONT		TYPE	QTY	PART NUMBER
<p>LEAF SPRING Type 'A'</p> <p>6 Leaves Raised Height (45mm Lift)</p>		A	2	TOY-055-F
<p>SHACKLE BUSH KIT Rubber Polyurethane Metal</p> <p>Kit Contains: 12 x SPF2231A</p>		B	1	PB59-1014K
<p>U-BOLT KIT</p> <p>Kit Contains: Right Hand Side 1 x UB59-453-1 1 x UB59-453-3</p>		A	1	UB59-450K
<p>Left Hand Side 2 x UB59-453-3</p>		A	1	UB59-453-3K
<p>SHOCK ABSORBER</p> <p>Heavy Duty Gas</p>		B	2	GS15-639S
<p>STEERING DAMPER Type 'A'</p> <p>Heavy Duty (Big Bore) Complete with Fittings</p>		A	1	SD59-823
<p>SHACKLE KIT</p> <p>Greasable: Fit in Pairs</p>		B	1	SK59-015
<p>Right Hand Side</p>		B	1	SK59-016
<p>Left Hand Side</p>		B	1	SK59-016

REAR		TYPE	QTY	PART NUMBER
<p>LEAF SPRING Type 'A'</p> <p>8 Leaves Raised Height (45mm Lift)</p>		A	2	TOY-056-R
<p>SHACKLE BUSH KIT Rubber Polyurethane Metal</p> <p>Kit Contains: 12 x SPF2231A</p>		B	1	PB59-1014K
<p>U-BOLT KIT</p> <p>Kit Contains: 2 x UB59-453-3</p>		A	2	UB59-453-3K
<p>SHOCK ABSORBER</p> <p>Heavy Duty Gas</p>		A	2	GS59-636
<p>SHACKLE KIT</p> <p>Greasable: Fit in Pairs</p>		B	1	SK59-015
<p>Right Hand Side</p>		B	1	SK59-016
<p>Left Hand Side</p>		B	1	SK59-016